


Step 1:



Draw 2mL of Sodium Citrate Anticoagulant into 20mL Syringe. Attach butterfly needle and prime tube for blood draw

Step 2:



Draw 18mL whole blood from the patient, filling the syringe to 20mL

Step 3:

**** PLEASE DISCARD RED VENTED CAP FROM CONCENTRATING DEVICE BEFORE USE ****



Slowly load anticoagulated whole blood into the **Concentrating Device**

Step 4:


Counterbalance and process the **Concentrating Device**

Platinum Centrifuge Process at:



AbsolutePRP® Gold

Executive Series II Process at:



1 Minute 4000 RPM


Step 5:



High Yielding PRP →

After centrifugation, the platelets will remain suspended in the plasma solution, forming the High Yielding PRP.

Step 6:



Attach the 12mL syringe and aspirate the High Yielding PRP, leaving the RBCs behind.



Final volume will be approximately 8 – 12 mLs