


Step 1:



Draw 5mL of Sodium Citrate Anticoagulant into 30mL Syringe. Attach butterfly needle and prime

Step 2:



Draw 25mL whole blood from the patient, filling the syringe to 30mL


Step 3:

**** PLEASE DISCARD RED VENTED CAP FROM CONCENTRATING DEVICE BEFORE USE ****



Load anticoagulated whole blood into the **Concentrating Device**


Step 4:



Counterbalance and process the **Concentrating Device** at


5 Minutes
4400 RPM

Step 5:




Attach the 30mL syringe and aspirate the plasma until the piston reaches the RBC interface (trapping the plasma & platelet buffycoat inside), then stop aspirating

Step 6:



Attach the 12mL syringe and aspirate 3-4mL PRP
(Rotate the syringe to re-suspend the platelet buffycoat into the plasma)

Step 7:



Attach the female-female connector to the plasma & PRP syringe. Aspirate plasma from the plasma syringe into the PRP syringe to attain the desired PRP volume.