


Note: Always swab self sealing port with sterile alcohol prior to accessing with a sterile syringe

Step 1:



Draw 3 mL of Sodium Citrate Anticoagulant into 30mL syringe


Step 2:



Draw 27 mL whole blood from the patient, filling the syringe to 30mL

Step 3:

**\*\* PLEASE DISCARD RED VENTED CAP FROM CONCENTRATING DEVICE BEFORE USE \*\***



Load anticoagulated whole blood into the **Concentrating Device**

Step 4:

**Executive Series Centrifuge**




Counterbalance and process the **Concentrating Device** at **5 minutes 4400 RPM**

**Platinum Series Centrifuge**




Counterbalance and process Set to **AbsolutePRP/BMC**

Step 5:



Attach the 30mL syringe and aspirate the plasma until the RBC interface reaches the 3mL volume marker, then stop aspirating.

Step 6:



Attach the 12mL syringe and aspirate 3-4mL PRP (Rotate the syringe to re-suspend the platelet buffycoat into the plasma)