


**Step 1:**



Draw 6mL of Sodium Citrate Anticoagulant into 60mL syringe


**Step 2:**



Draw 54mL of whole blood from the patient, filling the 60mL syringe

**Step 3:**

Please remove and **DISCARD RED CAP** from concentrating device before use



Load anticoagulated whole blood into the **Concentrating Device**. The blood will push the disc down.

**Step 4:**

**Executive Series Centrifuge**



Counterbalance and process the **Concentrating Device** at **7 minutes 4400 RPM**


---

**Platinum Series Centrifuge**




Counterbalance and process Set to **AbsolutePRP/BMC**

**Step 5:**



Attach the 60mL syringe and aspirate the plasma until the RBC interface reaches the 7mL volume marker, then stop aspirating

**Step 6:**



Attach the 12mL syringe and aspirate 7mL AbsolutePRP (Rotate the syringe to re-suspend the platelet buffycoat into the plasma)